



SST/SST-U SERIES

IST/IST-U SERIES

superTube Heaters

LOW INTENSITY TUBE TYPE INFRARED HEATER WITH HIGH EFFICIENCY EC Motor

ANSI Z83.20-2016 • CSA 2.34-2016



TWO STAGE — SUPPLEMENTARY MANUAL

A GENERAL INFORMATION MANUAL IS INCLUDED IN THE BURNER KIT

WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this heater.



SAFETY ALERT:

Do not store or use gasoline or other flammable vapours and liquids in the vicinity of this or any other gas fired appliance.

IF YOU SMELL GAS:



- Extinguish any open flame
- Do not attempt to light this or any other appliance
- Don't touch any electrical switch, or telephone
- Immediately call your gas supplier from a neighbor's phone
- Follow any and all instruction from your gas supplier



FIELD CONVERTIBILITY:

This appliance is field convertible to LP gas. Only use a kit available from manufacturer. Follow instructions provided in the kit and all local and national codes.

Keep this manual in a secure place

Record for future reference:

Model #: ------

Serial #: -----

NOTICE:

This manual is current and correct for this product at time of manufacture. Occasional revision of the product and/or Certification Standard may require changes to the product and/or this manual.

This publication, or parts thereof, may not be reproduced in any form, without prior written consent from The Manufacturer. Unauthorized use or distribution of this publication is strictly prohibited.

Schwank Group

Schwank and InfraSave brands

5285 Bradco Boulevard Mississauga, Ontario,L4W 2A6

2 Schwank Way

Waynesboro, Georgia 30730

Customer & Technical Services

Phone: 877-446-3727

Fax: 866-361-0523

e-mail: csr@schwankgroup.com

www.schwankgroup.com

www.infrasave.com

SST & IST SERIES: TWO-STAGE MODELS

• ALSO REFER TO THE GENERAL MANUAL INCLUDED FOR THIS SERIES HEATER

THIS SUPPLEMENTARY MANUAL: TABLE OF CONTENTS

TOPIC PAG	GE	ТОРІСР	AGE
APPLICATION	4	8B. WIRING DIAGRAM: MULTIPLE	
1. INPUT RATINGS AND DIMENSIONS	5	HEATERS PER THERMOSTAT	22
2. BURNER / TUBE KIT ASSEMBLY CHART	7	9. FENWAL DSI: SEQUENCE OF OPERATION	23
3. TURBULATOR LENGTH & LOCATION	11	SPARK IGNITER SET UP	25
4. COMBUSTION AIR DUCTING	13	FENWAL DSI SERVICE CHECK	25
5. FLUE VENTING:	14	10. TROUBLESHOOTING GUIDE: DSI	26
MIN./MAX. SYSTEM LENGTHS	15	11. TROUBLESHOOTING GUIDE: HEATER	27
HEATER EXPANSION & VENT	16	12. START- UP / COMMISSIONING SHEET	29
VERTICAL VENTING—CATEGORY I	17	13. GAS CONVERSION OF BURNER	31
HORIZONTAL VENTING—CATEGORY III	18	14. HIGH ALTITUDE & ORIFICE CHART 3	2 - 33
6. GAS SUPPLY PRESSURES	20	15. BURNER PARTS LIST	34
7. ELECTRICAL AND THERMOSTAT	20	16. TUBE SYSTEM PARTS LIST	36
8A. WIRING DIAGRAM: FENWAL DSI			
24V or 120V THERMOSTAT	21		

GENERAL MANUAL: TABLE OF CONTENTS

ТОРІС РА	GE	ТОРІС	PAGE
IMPORTANT INFORMATION - READ FIRST APPLICATION HEATER EXPANSION GAS CONNECTION VENTING START UP 'SMOKE' THERMOSTAT SETTING / COMFORT TUBE 'GLOW' CLEARANCE TO COMBUSTIBLES Clearances Figure & Table STACKING HEIGHT SIGN	<u>ST</u> 4 5, 31 5, 26 5 6 6 7 8	 7. SYSTEMS WITH 90° & 180° ELBOWS ELBOW KIT DIMENSIONS 8. SUSPENSION OF THE SYSTEM 9. BURNER & TUBE INSTALLATION: STRAIGHT TUBE SYSTEM SPECIAL COUPLING - 180 to 260 Mbh 10. SESMIC RESTRAINT HIGH WIND RESTRAINT 11. REFLECTOR INSTALLATION 12. GAS SUPPLY HEATER EXPANSION ELEXIBLE CAS CONNECTION 	12 13 14 15 18 19 19 20 21 22 22
 LABOR REQUIREMENTS INSTALLATION IN AIRCRAFT HANGARS COMMERCIAL GARAGES USE OTHER THAN SPACE HEATING PRE-INSTALLATION SURVEY MOUNTING CLEARANCES SERVICE CLEARANCE HEATER PLACEMENT GUIDELINES 	9 9 9 10 11 11 12	 13. ELECTRICAL AND THERMOSTAT 14. HIGH ALTITUDE INSTALLATION 15. LIGHTING INSTRUCTIONS 16. RECOMMENDED MAINTENANCE 17. OPTIONAL ACCESSORIES OPTIONAL CONTROLS WARRANTY STATEMENT BACK 	23 24 24 24 24 25 27 PAGE

WARNING



Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read and understand this installation and operation manual thoroughly prior to assembly, installation, operation or service to this appliance.

This heater must be installed and serviced only by a trained gas service technician.



Do not store or use gasoline or other flammable vapours and liquids in the vicinity of this or any other gas fired appliance.

Failure to comply could result in personal injury, death, fire and/or property damage.



Do not store or use gasoline or other flammable vapours and liquids in the vicinity of this or any other gas fired appliance.

This appliance may have sharp edges and corners. Wear protective clothing such as gloves and protective eye wear when servicing this or any other appliance.

California Proposition 65:

WARNING: This product can expose you to chemicals including carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov

APPLICATION

SST-T /IST-T Models are two-stage gas-fired radiant tube heaters that may be installed for heating of commercial / industrial indoor spaces. Not for use in residential dwellings.

A "residential dwelling" is defined in the standard as "a housekeeping unit used or intended to be used as a domicile by one or more persons, containing cooking, eating, living, sleeping, and/or sanitary facilities. A residential dwelling does not include an attached garage, detached garage, workshop or outdoors". Local Code requirements take precedence for this application.

It is beyond the scope of these instructions to consider all conditions and requirements that may be encountered in the field. Installation must conform with all local codes or, in the absence of local codes, with the latest edition of the National Fuel Gas Code, ANSI Z223.1/NFPA 54 in the U.S.A. or the Natural Gas and Propane Installation Code, CSA B149.1 in Canada. The latest edition Electrical Code ANSI/NFPA No. 70 in the U.S.A. and PART 1 CSA C22.1 in Canada must also be observed.

Installation of a gas fired tube heater must conform to all heating installation design procedures including clearance to combustibles, connection to the gas and electrical supplies, and ventilation requirements.

This heater is not for installation in a Class 1 or Class 2 explosive environment, nor in a residential dwelling. If installation of this equipment is in question, consult with the local authority having jurisdiction (Fire Marshall, labor department, insurance underwriter, or other).

Revisions to codes and/or standards, may require revision to equipment and installation procedures. In case of discrepancy, the latest codes, standards, and installation manual will take priority over prior releases.

1. TABLE 1: SST-T & IST-T MODEL INPUT RATINGS (BTUH) AND DIMENSIONS

TWO-STAGE INPUT RATE [BTUH]	FUEL TYPE	TUBE LENGTH STRAIGHT [FT]	OVERALL HEATER LENGTH [FT]	APPROX NET WEIGHT [LB]
50.000		20	21' 7"	111
50,000		30	31' 3"	154
65.000		20	21' 7"	111
05,000	NG/ FROFANE	30	31' 3"	154
80.000		20	21' 7"	111
80,000	NG/PROPANE	30	31' 3"	154
115 000		30	31' 3"	154
115,000	NG/ FROFANE	40	40' 11"	197
120.000		30	31' 3"	154
130,000	NG/ PROPANE	40	40' 11"	197
155 000		40	40' 11"	197
155,000	NG/ FROFANL	50	50' 7"	239
180.000		50	50' 7"	239
100,000	NG/ FROFANL	60	60' 3"	282
205 000		50	50' 7"	239
205,000	NG/ FROFANL	60	60' 3"	282
225 000		60	60' 3"	282
220,000		70	69' 11"	324
250 000		60	60' 3"	282
230,000	NG/FNOFANE	70	69' 11"	324

FIGURE 1 HEATER DIMENSIONS





2. TABLE 2: <u>SST-T/ IST-T SERIES TUBE KIT ASSEMBLY CHART</u>

BEFORE INSTALLING: ENSURE you have the CORRECT TUBE KIT(s) for the BURNER INPUT

	TUBE	BASE SYSTEM	BASE SYSTEM TUBE KIT(S)		
	LENGTH	PRIMARY KIT	SECONDARY KIT		SECOND TUBE
50,000	20	TD-P2AH-ST	-	Aluminized Steel	Hot Rolled Steel
50,000	30	TD-P3AH-ST	-	Aluminized Steel	Hot Rolled Steel
65,000	20	TD-P2AH-ST	-	Aluminized Steel	Hot Rolled Steel
65,000	30	TD-P3AH-ST	-	Aluminized Steel	Hot Rolled Steel
80,000	20	TD-P2AH-ST	-	Aluminized Steel	Hot Rolled Steel
80,000	30	TD-P3AH-ST	-	Aluminized Steel	Hot Rolled Steel
115,000	30	TD-P3AH-ST	-	Aluminized Steel	Hot Rolled Steel
115,000	40	TD-P4AH-ST	-	Aluminized Steel	Hot Rolled Steel
130,000	30	TD-P3AH-ST	-	Aluminized Steel	Hot Rolled Steel
130,000	40	TD-P4AH-ST	-	Aluminized Steel	Hot Rolled Steel
155,000	40	TD-P4AH-ST	-	Aluminized Steel	Hot Rolled Steel
155,000	50	TD-P3AH-ST	TD-S2HH-ST	Aluminized Steel	Hot Rolled Steel
180,000	50	TD-P3AH-ST	TD-S2HH-ST	Aluminized Steel	Hot Rolled Steel
180,000	60	TD-P3AH-ST	TD-S3HH-ST	Aluminized Steel	Hot Rolled Steel
205,000	50	TD-P3AH-ST	TD-S2HH-ST	Aluminized Steel	Hot Rolled Steel
205,000	60	TD-P3AH-ST	TD-S3HH-ST	Aluminized Steel	Hot Rolled Steel
225,000	60	TD-P4SS-STM	TD-S2HH-ST	Stainless Steel	Stainless Steel
225,000	70	TD-P4SS-STM	TD-S3HH-ST	Stainless Steel	Stainless Steel
250,000	60	TD-P4SS-STM	TD-S2HH-ST	Stainless Steel	Stainless Steel
250,000	70	TD-P4SS-STM	TD-S3HH-ST	Stainless Steel	Stainless Steel

RIES TUBE KIT SYSTEMS: INPUTS 50,000 TO 155,000 BTUH SYSTEMS FOR INPUTS 180,000 TO 250,000: NEXT PAGE	MATERIALS LEGEND: I XXXXXXXX TD-P2AH-ST A/S HRS HRS HRS S/S STAINI FSS STFFI TUBE	A/S HRS HRS TD-P3AH-ST	A/S HRS HRS TD-P3AH-ST	TUBE KIT NOMENCLATURE VS HRS HRS TD-P4AH-ST TD - P 4 S A - ST	Second Tube - Material	VS HRS HRS TD-P4AH-ST	VS HRS HRS HRS HRS HRS HRS HRS HRS HRS HR
ERIES TUBE KIT SYSTEM	A/S HRS TD-P2AH-	A/S HRS HRS	A/S HRS HRS	A/S HRS HRS		A/S HRS HRS	A/S HRS + HRS
TWO STAGE SST SE	50,000 65,000 × 20'	50,000 65,000 × 30' 80,000	115,000 x 30'	115,000 × 40'		155,000 x 40'	155,000 x 50'

,000 TO 155,000: PREVIOUS PAGE	<u>MATERIALS LEGEND:</u> A/S = ALUMINIZED STEEL TUBE HRS = HOT ROLLED STEEL TUBE S/S = STAINLESS STEEL TUBE	<pre>^</pre>	<u>NOTE:</u> For 180 & 205 MBH models, on 36" turbulator should be remove from the tube kit. Please see ne	instructions.			IRS		HRS HRS
SYSTEMS FOR INPUTS 50,			PRIMARY: TD-P3AH-ST		HRS HRS HRS HRS HI	PRIMARY: TD-P4SS-STM	A/S HRS HRS H ▲SECONDARY: TD-S2HH-ST>	PRIMARY: TD-P4SS-STM	A/S HRS HRS
			0 × 50' A/S HRS		0 x 60 A/S HRS		0 x 60' S/S S/S		0x 70' S/S S/S
			80,00 205,00	RO OO	05,00	25 00	50,00	25 OO	50,00

TWO STAGE SST SERIES TUBE KIT SYSTEMS: INPUTS 180,000 TO 250,000 BTUH

2. TABLE 2B: SST-TU/ IST-TU SERIES TUBE KIT ASSEMBLY CHART (U-TUBE MODELS)

INPUT	TUBE	BASE SYSTEN	TUBE KIT(S)		
[BTUH]	LENGTH	PRIMARY KIT	SECONDARY KIT		FIK21 TORE
50,000	10	TU-P10AH-SST	-	[2] x 2.25" x 36"	Aluminized Steel
65,000	10	TU-P10AH-SST	-	[2] x 2.25" x 36"	Aluminized Steel
80,000	10	TU-P10AH-SST	-	[2] x 2.25" x 36"	Aluminized Steel
115,000	15	TU-P15AH-SST	-	[3] x 2.25" x 36"	Aluminized Steel
130,000	15	TU-P15AH-SST		[3] x 2.25" x 36"	Aluminized Steel
155,000	20	TU-P20AH-SST		[2] x 2.25" x 36"	Aluminized Steel
180,000	25	TU-P15AH-SST	TU-S10HH-SST	[1] x 2.25" x 36"	Aluminized Steel
205,000	25	TU-P15AH-SST	TU-S10HH-SST	[1] x 2.25" x 36"	Aluminized Steel
225,000	30	TU-P20SS-SST	TU-S10HH-SST	No Turbulator	Stainless Steel
250,000	30	TU-P20SS-SST	TU-S10HH-SST	No Turbulator	Stainless Steel

TWO-STAGE SST-SU SERIES TUBE KIT SYSTEMS (U-Tube Models)



3. TURBULATOR LENGTHS & LOCATION IN SYSTEM



NOTE: Improper location of a turbulator can cause malfunction of the heater, property damage, and will void the heater warranty.

Tubes with turbulators inside are clearly labeled for easy identification.

ALL turbulators are located within the BASE LENGTH (shortest length) of the tube system. One or two tubes added to system base length are regular empty tubes with no turbulators.

Each turbulator is 36 inches in length by 2.25" width (see Table below).

Turbulators link together with tabs, and individual sections can be removed by straightening tabs (see below). A Base Tube Kit may need turbulator removal depending on input rate (see below and illustration next page).

The orientation of the turbulator(s) [up - down; sideways] in the tube does not matter.

TABLE 3: TURBULATORS: QUANTITY AND LOCATION IN TUBE SYSTEM

FUEL TYPE	MODEL Input x Base Length (FT)	TURBULATOR [QUANTITY] x WIDTH x LENGTH	TURBULATOR LOCATION IN BASE LENGTH	INSTALLER ACTION RE- QUIRED: REMOVE & DISCARD TURBULATOR SECTION
NG or LP	50,000 x 20	[3] x 2.25" x 36"	3 IN 2nd TUBE	No action required
NG or LP	65,000 x 20	[3] x 2.25" x 36"	3 IN 2nd TUBE	No action required
NG or LP	80,000 x 20	[3] x 2.25" x 36"	3 IN 2nd TUBE	No action required
NG or LP	115,000 x 30	[3] x 2.25" x 36"	3 IN 3rd TUBE	No action required
NG or LP	130,000 x 30	[3] x 2.25" x 36"	3 IN 3rd TUBE	No action required
NG or LP	155,000 x 40	[3] x 2.25" x 36"	3 IN 4th TUBE	No action required
NG or LP	180,000 x 50	[2] x 2.25" x 36"	2 IN 5th TUBE	Remove 1 turbulator from 5th tube
NG or LP	205,000 x 50	[2] x 2.25" x 36"	2 IN 5th TUBE	Remove 1 turbulator from 5th tube
NG or LP	225,000 x 60	[1] x 2.25" x 36"	1 IN 6th TUBE	No action required
NG or LP	250,000 x 60	[1] x 2.25" x 36"	1 IN 6th TUBE	No action required

TURBULATOR SECTION REMOVAL: Models: 180,000 & 205,000 BTUH

1.Carefully pull out the turbulator section to be removed from the swaged end of the tube. The end of the turbulator to be left inside the tube should not extend beyond the swaged portion of the tube. Rotate the tube to have access to the locking tab

FIGURE 3



2. Bend and push the outer tab with pliers until it is in the vertical position



3. Lift up the end of the turbulator that is left inside the tube to disengage the tab that was bent in the vertical position 4. While still holding the inner turbulator in its location, pull the outer turbulator to completely disengage and discard





SST / IST TWO-STAGE I&O Manual RD: SEP 2020 RL: 3B

SST SERIES TURBULATORS: LOCATION IN BASE SYSTEM TUBE KITS



4. <u>COMBUSTION AIR DUCTING</u>

Do not install filters on the combustion air intake. Ensure adequate clearance around the air intake to allow sufficient combustion air supply to the burner.

Air duct is typically 4" diameter, but inputs 205,000 and greater require a minimum 5" diameter duct (reduce to 4" at burner connection). Any 4" duct can be increased to 5" diameter to allow up to an additional 20 feet of duct length.

Combustion air duct must be constructed of noncombustible material. **Do not use a 'soft wall' flexible hose** for air duct, the corrugated sides of this tubing will contract and restrict air flow. A good quality industry approved hard-wall flex is allowed.

When a tube heater is operated in a negative air condition or air-born dust or contaminants are present as in woodworking, and welding shops, air for combustion must be ducted from outside the negative or contaminated area to the 4 inch (10 cm) diameter intake flange supplied on the blower. Maximum system, vent and duct length is listed above.

- Do not exceed lengths listed above for total system and individual vent or air duct
- Total combined system length is reduced by five feet for every 90° elbow installed in the vent or duct *and* in the tube system (see above for allowable total lengths)
- Exceeding the allowable lengths may create condensation or soot conditions and will void product certification and warranty

The air intake will not be located less than:

- Three feet above grade
- Twelve inches from flue vent terminal of any heater with input up to 100,000 Btu/hr
- Three feet from flue vent terminal of any heater over 100,000 Btu/hr

An optional horizontal fresh air intake hood (JS-0532-VC) is available to bring combustion air to the heater from an outside wall. If dropping air duct down from the roof, use an approved rain cap for the duct terminal. Ensure adequate clearance around the air intake to allow sufficient combustion air supply to the heater. When drawing freeh air free outside, it is recent

supply to the heater. When drawing fresh air from outside, it is recommended that any single wall pipe containing cold air be insulated to reduce condensation on the pipe surface.

NOTE: When outside-air duct drops down from the roof:

- Drop air duct to a Tee / drip leg to the side of the burner
- This will potentially reduce condensate and other moisture accumulation at the blower





In locations where chlorinated Hydrocarbons are in use, such as Trichloroethylene or Chloroethylene Nu it is essential that combustion air be brought in from a noncontaminated area. Burning the fumes from these gases will create Hydrochloric acid fumes, which are detrimental to humans, equipment and buildings. Typical sources of other contaminants are paint removers, paints, refrigerants, solvents, adhesives, degreasers, lubricants, pesticides, etc.



The heater manufacturer cannot anticipate all types nor chemical composition of potential contaminants at project sites. Prior to installation, confer with project site safety, health and engineering staff and/or local authorities having jurisdiction such as the Fire Marshall and Department of Labor for possible contaminants and any conflict with the installation of hot surface heating equipment.

5. FLUE VENTING - RADIANT TUBE HEATER



Effective immediately for this tube heater series: Changes to the ANSI/ CSA standard that governs Radiant Tube Heaters specify the following appliance CATEGORIES and VENTING:

- Vertical Vent Through Roof (Category I): When vented vertically, this tube heater series operates with a negative static vent pressure and a vent temperature that does not result in excessive condensate in the vent and is defined as a Category I appliance. Refer to details below.
- Horizontal Vent Through Wall (Category III): For horizontal vent, this tube heater series operates with a positive static vent pressure and a vent temperature that does not result in excessive condensate in the vent and is considered a Category III appliance. Refer to details below.



Inadequate venting of a heater may result in asphyxiation, carbon monoxide poisoning, injury or death. This heater may use a vent connection or indirect venting system to remove products of combustion from the space. Seal all

vent connections with high temperature sealant. Venting must be in accordance with all local, state, provincial, and national codes (ANSI Z223.1/NFPA 54 in USA; B149.1 in Canada) and as indicated below in this manual.

This tube heater is certified for venting directly to the outside or unvented (indirect venting) applications.



UNVENTED (INDIRECT MECHANICAL VENTING SYSTEM)

<u>USA</u>: Natural or mechanical means shall be provided to supply and exhaust at least 4ft³/ min/1000Btuh (0.38m³/min/kW) input of installed heaters. Some local codes may require an electrical interlock to a dedicated exhaust fan. Exhaust must be located as high as practicable in the structure above the level of the heater(s). Consult your local code and ANSI Z223.1 latest edition for all venting requirements and practices.

<u>**Canada**</u>: It is required that the heater(s) be electrically interlocked to dedicated exhaust fan(s) by means of an Air Proving Switch. Exhaust fan(s) must be sized to create 300 cfm (8.5 cu m/min) exhaust for every 100,000 Btuh (30 kW) or any fraction thereof of total input of installed equipment. Exhaust must be located as high as practicable in the structure above the level of the heater(s). Sufficient supply air must be provided. Consult the latest edition of CSA.B149.1 Section 8 for venting system and air supply requirements.

VENTED TO THE OUTSIDE - GENERAL REQUIREMENTS

It is the responsibility of the installer to adhere to these instructions and all current local codes and/or ANSI Z223.1 (NFPA 54) or CSA.B149.1 latest editions for all venting requirements, and practices. All vent pipe will be certified to meet Category I (vertical vent) or Category III (horizontal vent) appliance requirements, depending on the vent configuration of a particular installation.

It is a normal condition that during heat-up and cool-down a tube heater will expand and contract. <u>Allowances for heater expansion must be made in the venting and combustion air ducting</u>. Improper installation can result in property damage, injury or death.

- When vented: The system must not be operated in a negative air condition unless combustion air is ducted from outside to the burner. If negative pressure is experienced or anticipated, the open port (barb) on each of the blocked flue and proving air switches must be Tee'd together and connected directly to outside air using a field supplied 1/4" plastic hose from the tee between the switches to outside of building.
- All approved vent pipe, connectors, and adapters are supplied locally by others according to

appliance Category, and specifications below

- Do not mix vent components from different manufacturers in the vent system
- All venting must meet requirements of Local Codes or, in the absence of local codes, with the National Fuel Gas Code, ANSI Z223.1/NFPA 54; or the Natural Gas and Propane Installation Code CSA B149.1
- A vent connector shall comply with local codes and be firmly attached to the flue collar by 3 x 1/2" sheet metal screws
- Install a minimum 12" [305 mm] straight vent connector before any Tee or 90° Elbow
- The connection of vent components must be secured as specified in the installation instructions by the vent manufacturer.
- For vertical vent, any horizontal vent section will slope upwards away from the heater not less than 1/4 inch rise per foot of run.
- For horizontal vent, slope downward away from heater a maximum of 1/4 inch down per foot of run
- When the vent pipe passes through a cold or unheated area where the ambient temperature is likely to produce condensation of the flue gases, the vent pipe will be insulated with a suitable material as certified and specified by the insulation manufacturer to withstand temperature up to 460°F (238°C).
- The vent system must **always** be adequately supported to prevent sagging.
- The vent configuration will allow for expansion and contraction in length of the tube heater
- As an Option for vertical vent, two heaters may be vented through an approved common 4" x 4" x 6" Vent Tee (10 x 10 x 15 cm), supplied by the manufacturer, or by using approved components as indicated in local codes. Vent pipe from each heater is not required to be equidistant to the vent Tee, but must comply with local code requirements. A common thermostat or "ON/OFF" switch must control the two commonly vented heaters. Common vent is not allowed for Category III horizontal vent application.

COMBINED SYSTEM LENGTH: Tube Heater + Vent + Combustion Air Duct:

- Refer to Table 4 next page, COMBINED SYSTEM LENGTH: TUBE + AIR DUCT + VENT. Lengths in the table apply to either Vertical or Horizontal vent.
- COMBINED SYSTEM LENGTH includes: Tube Heater length + combustion air duct + vent + elbows. Each 90° elbow in the system has an equivalent length of 5 ft.
- A maximum of 2 elbows is allowed in any portion (duct, tube heater, vent) with the exception of up to three 90° elbows in a vertical vent run through the roof, for a total of maximum 6 (vertical vent: 7) 90° elbows in the combined system
- Combustion air duct is not to exceed lengths in table below and may be 4" or 5" diameter for inputs less than 200,000 Btuh, but must be 5" diameter for inputs 200,000 Btuh and greater
 - 5" diameter duct requires a reducer to 4" diameter at the connection to blower inlet
- Exceeding the allowable lengths in the table below can create combustion and/or condensation issues and will void Certification and the heater warranty.
- Do not exceed the Maximum Combined System Length regardless of the allowed maximum length of individual vent or combustion air duct

TABLE 4 COMBINED SYSTEM LENGTH: TUBE + AIR DUCT + VENT

TWO- STACE Do Not Exceed Maximum Combined System Length		Exceed Combined	Max. A Len	ir Duct I gth Diameter)	Max. Vent Length		
Input (Btuh)	With 4"	With 5"	4" Ø	1" Ø 5" Ø Combined: 6		Example	
	Air Duct	Air Duct		0.0	Combined. 0 Ø	<u>155,000 Biun Heater:</u>	
50,000 & 65,000	70 ft	80 ft	20 ft	30 ft	30 ft	Tube Heater Length	50 ft
						1 x 90° elbow (vent)	5 ft
115,000 &	80 ft	90 ft	20 ft	30 ft	30 ft	Straight vent	15 ft
130,000 &	00.6	400.5	00.4	00 ft	00.4	1 x 90° elbow (duct)	5 ft
155,000	90 ft	100 π	20 π	30 π	30 π	Air Duct: 4" Ø	<u>15 ft</u>
180,000	100 ft	110 ft	20 ft	30 ft	30 ft	Combined Length	90 ft
205,000	Use 5"Ø	110 ft	Use 5"Ø	30 ft	30 ft	Max. Allowed	90 ft
225,000 to 250,000	Use 5"Ø	120 ft	Use 5ӯ	30 ft	30 ft	Additional 10' for 5" Ø Air	[.] Duct

HEATER EXPANSION AND VENT CONFIGURATION

A radiant tube heater will expand and contract as it heats and cools. Configuration of the vent must allow for heater expansion.

VERTICAL VENT: Orientation of the vent at 90° to heater will allow for heater expansion and contraction.

HORIZONTAL VENT: (See FIG. 6)

Wall Thimble or flashing at wall that allows movement of the vent through the opening. Do not seal the vent to the thimble or flashing with caulking

OR

- Offset vent with two x 90° elbows. Install minimum 12 inch [305 mm] length of straight vent between elbows. Vent can be sealed with caulking at non-combustible wall.
- Other means of slip fit installation of the vent are acceptable providing there is adequate allowance for free expansion and contraction of the system, and free flow of

FIGURE 6: ALLOW FOR HEATER EXPANSION - HORIZONTAL VENT - TOP VIEW



COMMON VENTING

For vertical vent only, two heaters can be commonly vented using 4"x 6"x 4" Vent Tee JA- 0514-XX. Both heaters must be operated using one common thermostat. Common vent is 6 inch [150 mm] diameter.

Category III (horizontal vent) heaters cannot be common vented.

VERTICAL VENT THROUGH THE ROOF (CATEGORY I):

It is the sole responsibility of the installer to adhere to all current local codes and/or ANSI Z223.1 / CSA.B149.1 latest editions for all venting requirements, and practices. Also adhere to instructions below, and the instructions of the vent manufacturer. Use vent materials certified for Category I.

All models of this series heater are certified Category I for vertical venting. See FIG. 5.

- The vent must extend at least 5 feet [1524 mm] above the flue collar of the highest connected heater
- USA: Horizontal run of single wall vent or vent connector ("H" in FIG 5) must not exceed 75% of the vertical height of the vent. If it does, then the vent system must be for Category III.
- Inputs up to 170,000 Btuh vertical vent can be 4" diameter Type B-Vent; greater than 170,000 Btuh must use 5" diameter Type B-Vent
- A vent connector must be secured to the flue collar using quantity 3 x #8 x 1/2" sheet metal screws
- A horizontal vent connector shall be installed and supported without any dips or sags and shall slope upward toward the vent or chimney at least 1/4 in./ft (20 mm/m).
- Use a certified termination cap as supplied by the manufacturer of the vent
- When vent and combustion air are taken through the roof, the exhaust vent should always terminate higher than the combustion air intake, to prevent recycling the products of combustion back into the heater
- The vent must extend at least 2 feet [610 mm] above the highest point where it passes through a roof. The vent must also extend at least two feet higher than any portion of a building within a horizontal distance of 10 feet [3 m].
- Keep vent connector runs as short as possible with a minimum number of elbows. Refer to the current edition of AN-SI Z223.1 (NFPA 54)or CSA-B149 installation codes for maximum length of horizontal vent and vent connector.
- Total length of the vent connector and vent pipe cannot exceed the values in Table 4 above.
- A single-wall vent connector shall not be insulated.
- For single-wall vent clearance to combustibles is 6" [152mm] except where a listed clearance thimble is used. Clearance to combustible material for Type B-Vent or factory-built vent per the vent manufacturer's instructions.



FIGURE 7: VERTICAL VENT

HORIZONTAL VENT THROUGH THE SIDEWALL (CATEGORY III):

- When installed with a horizontal vent through a sidewall, this heater is a Category III appliance, and venting materials must be approved for Category III applications.
- All vent must be installed in accordance with local codes or, in the absence of local codes, with the National Fuel Gas Code, ANSI Z223.1/NFPA 54; or the Natural Gas and Propane Installation Code CSA B149.1.
- All vent must installed in accordance with these instructions, and the instructions of the vent manufacturer.
- Do not mix vent components from different manufacturers in the vent system
- A single wall vent system may use a single continuous section of double wall vent pipe to pass through an exterior wall.
- Any horizontal portion of the flue vent system must slope downwards away from the heater a minimum of 1/4" per foot run [63 mm/ 300 mm] toward the vent terminal.
- All vent pipe from a single heater must be 4" [102 mm] diameter; common vent pipe for two heaters must increase to 6" [152 mm] at the point of connection of individual 4" vents
- Use approved 4" [102 mm] (JA-0528-XX) or 6" [152 mm] (JA-0529-XX) horizontal wall vent terminal or an approved high-wind termination cap
- Installation of the vent must prevent blockage by snow and protect building materials from degradation by flue gases.
- Install termination cap a minimum of 18 inches (45 cm) from the outside wall to the inside edge of terminal opening to alleviate back pressure caused by turbulent wind conditions (See Fig. 8). This also ensures flue gases are directed away from the structure to protect building materials from degradation by the exhausted flue gases.
- At most two 90° elbows can be installed in a horizontal vent
- A horizontal flue vent will not terminate less than 1 ft [30 cm] above grade level, unless its location is adjacent to public walkways, then it must not terminate less than 7 ft [2.1m] above the walkway.
- Clearance below a combustible overhang or soffit:
 - As indicated in FIGURE 8 for approved terminations: 4" [100 mm] JA-0528-XX or 6" [150 mm] JA-0529-XX
 - For other approved terminations: Will terminate 3 ft [915 mm] or more below a combustible soffit or overhang.
- A horizontal vent termination must be a minimum of 6 feet [1830 mm] from an inside corner formed by two exterior walls.
- A venting system shall be securely supported by noncombustible hangers suitable for the weight of the materials.
- A slip joint in the horizontal section of a venting system shall be secured with quantity 3 x #8 x 1/2" sheet metal screws to prevent sagging.
- Seal single-wall vent seams and joints with Dow Corning 736 Heat Resistant Sealant 600°F [315°C] or equivalent, or follow the instructions of the vent manufacturer for sealing vent pipe connections

USA and Canada specific requirements for horizontal vent are on the next page

USA specific horizontal vent requirements:

- The vent terminal of an appliance with an input up to 50,000 Btu/hr (14.7kW) shall be installed with a 9 inch [230mm] vent termination clearance from any air opening into a building, and an appliance with an input over 50,000 Btu/hr (14.7kW) shall have at least a 12 inch [305 mm] vent termination clearance. The bottom of the vent terminal and the air intake shall be located at least 12 inches [305 mm] above grade.
- A horizontal vent will not terminate:
 - Less than 3 ft [915 mm] above a mechanical air inlet located within 10 ft [3 m]
 - Less than 4 ft [1219 mm] below, 4 ft [1219 mm] horizontally from, and 1 ft [102 mm] above any window or door that opens, or gravity air inlet to a building
 - Less than 4 ft [1219 mm] horizontal clearance from gas and electric meters, regulators and relief equipment

CANADA specific horizontal vent requirements:

- A horizontal vent will not terminate:
 - Within 6 ft [1830 mm] of a mechanical air supply inlet to any building.
 - Above a gas utility meter and regulator assembly within 3 ft [915 mm] horizontally of the vertical centerline of the regulator vent outlet to a maximum vertical distance of 15 ft [4.5 m].
 - Within 3 ft [915 mm] of any gas pressure regulator vent outlet
 - Within the following distances of a window or door that can be opened in any building, of any non-mechanical air-supply inlet to any building, or of the combustion air inlet of any other appliance:
 - 12 inches [305 mm] for inputs up to and including 100,000 Btuh (30 kW)
 - 3 ft [915 mm] for inputs exceeding 100,000 Btuh (30 kW)

FIGURE 8: HORIZONTAL VENT THROUGH WALL



6. GAS SUPPLY: MINIMUM / MAXIMUM & MANIFOLD PRESSURES

Refer to General Manual for requirements on gas supply and flexible gas connection to the heater.

		LINE PF	RESSURE	MANIFOLD PRESSURE
INPUT	FUEL TYPE	INCHES WA	TER COLUMN	(tap at gas valve outlet) INCH-
		MINIMUM	MAXIMUM	ES WATER COLUMN
TWO-STAGE	Natural Gas	5.0	14.0	3.5 / 2.0 (4.2 / 2.0 FOR 225&250 MBH)
	Propane	11.0	14.0	10.0 / 5.0

TABLE 5 Manifold Pressure - Two Stage Models

7. <u>ELECTRICAL AND THERMOSTAT WIRING</u> (WIRING DIAGRAMS NEXT PAGES)



The heater must be electrically grounded in accordance with the National Electrical Code. ANSI / NFPA 70 or current Canadian Electrical code CSA C22.1.

Appliance and control wiring must be in accordance with all applicable local codes. The total load of all heaters must be considered in determining the required contact rating of the controlling thermostat or switch. Each tube heater requires 120V, 60 HZ electrical power sized for 145VA. Maximum power flow for internal 24V burner components is 21VA.

The Fenwal ignition control includes a 24V/120V relay switch that provides a 45 second pre-purge and 45 second post-purge of the system. To maintain function of the post-purge feature, any **Thermostat / control must be installed in the thermostat circuit from the terminal block (TR - TW).** A line voltage Thermostat or an "ON/OFF" control switch installed in the 120VAC power supply will disable the post-purge feature.

A maximum night set-back of 9°F (5°C) is recommended for optimum economy and comfort. To maintain satisfactory comfort levels do not turn off the heating system over night/weekends.

8A. <u>SST-T/ IST-T WIRING DIAGRAM</u>: 24V OR 120 VOLT THERMOSTAT OPERATION <u>SINGLE HEATER PER THERMOSTAT</u> (Multiple Heaters per Thermostat—next page)



8B. MULTIPLE TUBE HEATERS per COMMON THERMOSTAT



9. FENWAL DSI: SEQUENCE OF OPERATION / FLAME RECOVERY / SAFETY LOCKOUT

Power Up / Stand By

Upon applying 24 volts power to 24VAC, the control will reset, perform a self check routine, initiate full time flame sensing, and enter the thermostat scan state.

Heat Mode

When a call for heat is received from the thermostat supplying 24 volts to TH, the control checks the pressure switch for normally open contacts. The combustion blower is then energized and once the pressure switch contacts close, a 30 second purge delay begins. Following the purge period the gas valve is energized and spark commences for the 15 second trial for ignition.

When flame is detected during the trial for ignition, spark is shutoff immediately and the gas valve combustion blower remains energized. The thermostat, pressure switch, and main burner flame are constantly monitored to assure the system continues to operate properly. When the thermostat is satisfied and the demand for heat ends, the main valve is de-energized immed-iately, the control senses the loss of flame signal and initiates a 30 second post-purge period before de-energizing the combustion blower.

Failure to Ignite - Lockout (THREE TRIAL MODEL)

This three-try control will attempt two additional ignition trials with a 30 second inter-purge between trials, before going into 'soft' lockout. The valve relay will be de-energized immediately, and the combustion blower will be turned off following the 30 second post purge period.

If the thermostat continues to call for heat after one hour the control will automatically reset and attempt to ignite the burner again (three trials).

At any time less than the 1 hour auto-reset, recovery from lockout requires a manual reset by either resetting the thermostat or removing 24 volts for a period of 5 seconds.

Flame Failure - Re-cycle

If the established flame signal is lost while the burner is operating, the control will go to recycle mode. The HV spark will be energized for a trial ignition period in an attempt to relight the burner. If the burner does not light the control will de-energize the gas valve. Two more attempts will be made to relight the burner. If the burner does not relight the control will go into 'soft' lockout as not-ed above in "Failure to Light". If flame is re-established, normal operation resumes.

Combustion Airflow Problems -Lockout

Combustion air flow is continually monitored during an ignition sequence by the air flow switch (PSW). If during the initial call for heat the pressure contacts are in the closed position for 30 seconds without an output to the Combustion Blower, an air flow fault will be declared and the control will remain in this mode with the combustion blower off.

If the air flow switch remains open for more than 30 seconds after the combustion blower output (L1 & IND) is energized, an air flow fault will be declared and the control will stay in this mode with the combustion blower on, waiting for the air flow switch to close.

When proper air flow is detected from the air flow switch input (PSW) the control begins the prepurge period followed with a 15 second ignition sequence.

If the air flow signal is lost while the burner is firing, the control will immediately de-energize the gas valve and the combustion blower will remain on. If the call for heat remains, the control will wait for proper air flow to return. If proper air flow is not detected after 30 seconds an air flow fault signal will be declared. If proper air flow is detected at any time, a normal sequence will begin with the pre -purge period.

Flame Fault

If at any time the main valve fails to close completely and maintains a flame, the full time flame sense circuit will detect it and energize the combustion blower. Should the main valve later close completely removing the flame signal, the combustion blower will power off following the optional post purge period.

MOUNTING AND WIRING

The Series 35-61 is not position sensitive and can be mounted vertically or horizontally. The case may be mounted on any surface with #6 sheet metal screws. All wiring must be done in accordance with local and national electrical code. Refer to wire diagram page 35 when connecting the Series 35-61 to other components in the burner.



WARNING

The Series 35-61 DSI Control uses voltages of shock hazard potential. Wiring and initial operation must be done by a qualified service technician. The control must be secured in an area that will experience a minimum of vibration and remain below the operating temperature of 160°F. All connections should be made with UL approved 105°C rated 18 gauge, stranded, .054 thick insulated wire. Refer to wire diagram page 35 when connecting the Series 35-61 to other components in the burner.

TERMI- NAL	SPADE	DESIGNATION
TH	1/4"	Thermostat Input
PSW	1/4"	Pressure Switch Input
V1	1/8"	Valve Power (MV)
IND	1/4"	Inducer Blower Output
NC	-	Alarm (Not used)
L1	1/4"	120/240 VAC Input (Hot)
24 VAC	1/4"	24 VAC Supply to Processor
V2	1/8"	Valve (MV)
GND	1/8"	Valve & System Ground
Spark	1/4"	Spark & Local Flame Sense

CAUTION:

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. A functional checkout of a replacement control is recommended.

PROPER ELECTRODE LOCATION

Proper location of the electrode assembly is important for optimum system performance. The electrode assembly should be located so that the spark gap is inside the flame envelope about 1 inch (2.5 cm) from the base of the flame at the burner cup.



Electrodes should have a gap spacing of 3/16" (0.188" \pm 0.031" or 4.76 mm \pm 0.81 mm). If this spacing is not cor-

rect, the assembly must be adjusted or replaced. DO NOT adjust the curved igniter/sensor prong. Adjust/bend only the ground prong (also see next page).

SPARK IGNITER SET UP

Use the following diagram to check the Igniter gap. If the gap is incorrect all adjustments should be made to the GROUND PRONG/PIN ONLY! DO NOT BEND THE IGNITER PRONG!!!!



Meter should read 0.7 μ A or higher. If the meter reads below "0" on scale, meter leads are reversed. Disconnect power and reconnect

ů

BLACK (-)

Ó

10. TROUBLESHOOTING GUIDE - FENWAL DSI

(also see Heater Troubleshooting next page)

SYMPTOM	RECOMMENDED ACTION(S)
1. Dead	 A. Miswired - check electrical supply (120Vac ± 5%) B. Transformer bad (24Vac ± 10%) C. Fuse/Circuit breaker bad D. Bad control (check LED for steady on) E. 24VDC Power Unit is bad
2. Thermostat on - no blower output	 A. Miswired B. Bad thermostat no voltage @ terminal W C. Bad control (check LED for steady on) D. 24VDC Power Unit is bad
3. Pressure switch input okay, but no Trial-for- Ignition after purge delay	 A. Miswired (check PSW terminal voltage: 24Vac ± 10%) B. Flame sense problem (existing flame: check LED - 2 flashes) C. Bad control (check line voltage between L1 & IND)
4. Valve on, no spark	A. Shorted electrodeB. Open HV cableC. Bad control
5. Spark on, no valve	 A. Valve coil open B. Open valve wire C. Bad control (check 24Vac voltage between V1 & V2)
6. Flame ok during TFI, no flame sense (after TFI)	 A. Bad electrode B. Bad HV igniter wire C. Poor ground at burner D. Poor flame (check flame current)

11. TROUBLESHOOTING GUIDE - HEATER OPERATION



Improper adjustment, alteration, service or maintenance can cause property damage, injury or death. This heater must be installed and serviced only by a trained gas service technician

SEQUENCE OF EVENTS (also see DSI Troubleshooting previous page)





12. START-UP / COMMISSIONING SHEET



THIS EQUIPMENT HAS BEEN FACTORY FIRED AND TESTED PRIOR TO SHIPMENT. HOW-EVER, THIS APPLIANCE IS NOT "PLUG & PLAY". IT REQUIRES COMMISSIONING AND FIELD ADJUSTMENT / SPECIFICATIONS CONFIRMATION TO ENSURE SAFE AND EFFI-CIENT OPERATION.

COMMISSIONING REPORT AS PER I&O MANUAL AND LOCAL CODES

CONTRACTOR NAME:	DATE
ADDRESS:	
CITY:	
PHONE:	
CELL:	
JOB SITE	CIT Y
Located on burner rating plate	

HEATER SERIAL NUMBER: Located on burner rating plate

TO ENSURE THAT SITE CONDITIONS ARE COMPATIBLE WITH THE HEATER'S PERFORMANCE AND TO ALLEVIATE NUISANCE CALL-BACKS, THE FOLLOWING START-UP NEEDS TO BE COMPLETED BY THE QUALIFIED GAS INSTALLER.

A TECHNICIAN CALLING FOR TECHNICAL SUPPORT MUST PROVIDE THE INFORMATION FROM THE COMPLETED COMMISSIONING REPORT ON THE NEXT PAGE

FAX COMPLETED REPORT TO TECHNICAL SERVICES:



START UP 'SMOKE'

During start up, material coatings used in the production process of tubes and reflectors will "burn off" and create smoke during the first hour of operation. This is temporary and normal.

Please ensure that there is sufficient ventilation to adequately clear the smoke from the space.

Notify site and safety personnel to ensure that alarm systems are not unduly activated.

QUALIFIED INSTALLER TO COMPLETE THIS

TYPE OF GAS:	NG	LP
DOES BUILDING HAVE A NEGATIVE CONDITION:	YES	NO 🔲
IF THIS IS A HIGH ALTITUDE AREA WHAT IS THE ALTITUDE ABOVE SEA I		Ft
DOES APPLICATION REQUIRE FRESH AIR TO BURNER	YES	NO 🔲
IS HEATER EXPOSED TO CHEMICAL OR CORROSIVE ATMOSPHERE:	YES	NO 🔲
ARE ACTUAL MINIMUM CLEARANCES AS PER TABLE 3	YES	NO 🔲
CAN HEATER BE AFFECTED BY OVERHEAD CRANES / VIBRATION	YES	NO 🔲
ARE GAS SUPPLY LINES ADEQUATELY SIZED FOR SYSTEM	YES	NO 🔲
GAS LINES AND BRANCHES HAVE BEEN PURGED OF AIR:	YES	NO 🔲
THIS HEATER FIRED WITHOUT ANY MALFUNCTION:	YES	NO 🔲
INLET GAS SUPPLY PRESSURE WITH HEATER OPERATING :		WC"
GAS VALVE OUTLET (Manifold) PRESSURE WITH HEATER OPERATING:		WC"
WHAT IS THE LINE VOLTAGE READING AT THE HEATER		VOLTS
WHAT IS THE VOLTAGE READING AT THE IGNITION MODULE		VOLTS
WHAT IS THE FLAME SIGNAL STRENGTH IN UA FROM SENSOR:	uA	(microamps)
IS HEATER CONTROLLED BY A THERMOSTAT	YES	NO 🗌
IS THE THERMOSTAT STRATEGICALY LOCATED	YES	NO 🛄
WHAT IS TOTAL LENGTH OF INSTALLED THERMOSTAT WIRE		FEET
WHAT IS THE GAUGE OF THE THERMOSTAT WIRE		GAUGE
WHAT IS THE HEATER TUBE LENGTH (10ft per Tube section)		FEET
WHAT IS THE TOTAL LENGTH OF THE VENT (add 10ft for each bend)		FEET
WHAT LENGTH IS COMBUSTION AIR INTAKE (add 10ft for each bend)		FEET
IF REQUIREDWHAT IS THE LENGTH OF THE TURBULATOR(S)		FEET
IF INSTALLEDIS TURBULATOR AT FLUE END OF SYSTEM	YES	NO 🔲
"MAXIMUM STACKING HEIGHT" SIGN(S) - POSTED AT THERMOSTAT(S)		

THIS HEATER MUST BE ELECTRICALLY GOUNDED

13. FIELD CONVERSION OF FUEL GAS: SST / IST TWO-STAGE BURNERS

Tube Heater Burners are factory produced and supplied to operate on natural gas.

A field conversion kit is available from the manufacturer and must be used to convert from natural gas to propane gas, or vice versa. Each kit contains the required parts and specific instructions to make the gas conversion.

Refer to the table below for kit part numbers.

NOTE: All Kits include a Gas Orifice*, and Valve Conversion Kit with Pressure Regulator Spring and Cap, and instructions to convert the gas valve and install the kit.

* Gas Orifice in the Field Conversion Kit:

- USA: 0 to 2,000 ft
- Canada: 0 to 4,500 ft
- Refer to "High Altitude" section for altitudes higher than listed above

** Call Factory for the Conversion Kit Part Number **

14. HIGH ALTITUDE INSTALLATIONS - Refer to chart below for Restrictions

When installed above the altitude stipulated below for USA and Canada, the input must be derated by 4% for each 1000 ft above the altitude listed. Refer to the tables below for orifice size and restrictions that apply to high altitude installation (including total system length restrictions). Check with your local utility regarding the gas supply and the de-rating of this appliance. Maintain gas supply pressure indicated in Section 4.

USA: The factory installed orifice for this appliance is approved for altitudes zero to 2000 feet above sea level.

Canada: The factory installed orifice for this appliance is approved for altitudes zero to 4500 feet above sea level.

14.A ORIFICE CONVERSION

Altitude Restrictions this Model:

- 1. Do not install at altitudes greater than 8,500 ft
- 2. Restrict the length of any model to the shortest tube length at altitudes greater than 4,500 ft

When this appliance is installed above the altitude stipulated in the Table below, the input must be de-rated by 4% for each 1000 ft of altitude. **If your local utility supplies gas with a de-rated heat content, no orifice change is required in the heater**. Check with your local utility regarding de-rating, and the following specifically for country of installation.

14. HIGH ALTITUDE INSTALLATION - ORIFICE TABLE ~ SEE NOTES ON PREVIOUS PAGE ~

SCHWANK/INFRASAVE RECOMMENDED ORIFICES - ALTITUDE CONVERSION

Canada: When installed above 4500 feet, refer to the Local Provincial Authority having jurisdiction .

	FOR USE AT ALTITUDES ABOVE (FEET)									
MODEL IN-	Gas Orifice Drill Size / Part#									
(MBH)	Supplied USA									
	0	2000	3000	4000	5000	6000	7000	8000		
50 NG	#29	30	30	30	31	31	32	32		
	JS-0729-DM	JS-0730-DM	JS-0730-DM	JS-0730-DM	JS-0731-DM	JS-0731-DM	JS-0732-DM	JS-0732-DM		
50 PROPANE	#46	46	47	47	47	48	48	49		
	JS-0746-DM	JS-0746-DM	JS-0747-DM	JS-0747-DM	JS-0747-DM	JS-0748-DM	JS-0748-DM	JS-0749-DM		
65 NG	#23	25	25	25	27	27	29	29		
	JS-0723-DM	JS-0725-DM	JS-0725-DM	JS-0725-DM	JS-0727-DM	JS-0727-DM	JS-0729-DM	JS-0728-DM		
65 PROPANE	#41	42	42	42	43	43	44	44		
	JS-0741-DM	JS-0742-DM	JS-0742-DM	JS-0742-DM	JS-0743-DM	JS-0743-DM	JS-0744-DM	JS-0744-DM		
80 NG	#17	18	18	18	20	22	22	24		
	JS-0717-DM	JS-0718-DM	JS-0718-DM	JS-0718-DM	JS-0720-DM	JS-0722-DM	JS-0722-DM	JS-0724-DM		
80 PROPANE	#37	38	38	39	40	40	42	42		
	JS-0737-DM	JS-0738-DM	JS-0738-DM	JS-0739-DM	JS-0740-DM	JS-0740-DM	JS-0742-DM	JS-0742-DM		
115 NG	#2	3	3	5	6	8	8	10		
	JS-0702-DM	JS-0703-DM	JS-0703-DM	JS-0705-DM	JS-0706-DM	JS-0708-DM	JS-0708-DM	JS-0710-DM		
115 PROPANE	#31	32	32	32	34	34	36	36		
	JS-0731-DM	JS-0732-DM	JS-0732-DM	JS-0732-DM	JS-0734-DM	JS-0734-DM	JS-0736-DM	JS-0736-DM		
130 NG	1	A	A	2	4	4	7	7		
	JS-0701-DM	JS-0700A-NS	JS-070A-NS	JS-0702-DM	JS-0704-DM	JS-0704-DM	JS-0707-DM	JS-0707-DM		
130 PROPANE	#30	31	31	31	32	32	33	33		
	JS-0730-DM	JS-0731-DM	JS-0731-DM	JS-0731-DM	JS-0732-DM	JS-0732-DM	JS-0733-DM	JS-0733-DM		
155 NG	G	F	F	F	D	B	B	1		
	JS-070G-NS	JS-070F-NS	JS-070F-NS	JS-070F-NS	JS-070D-NS	JS-070B-NS	JS-070B-NS	JS-0701-DM		
155 PROPANE	#26	27	27	28	29	29	30	30		
	JS-0726-DM	JS-0727-DM	JS-0727-DM	JS-0728-DM	JS-0729-DM	JS-0729-DM	JS-0730-DM	JS-0730-DM		
180 NG	M	K	K	K	J	H	H	F		
	JS-070M-NS	JS-070K-NS	JS-070K-NS	JS-070K-NS	JS-070J-NS	JS-070H-NS	JS-070H-NS	JS-070F-NS		
180 PROPANE	#21	23	23	25	26	26	27	27		
	JS-0721-DM	JS-0723-DM	JS-0723-DM	JS-0725-DM	JS-0726-DM	JS-0726-DM	JS-0727-DM	JS-0727-DM		
205 NG	R	P	P	P	N	N	M	M		
	JS-070R-NS	JS-070P-NS	JS-070P-NS	JS-070P-NS	JS-070N-NS	JS-070N-NS	JS-070M-NS	JS-070M-NS		
205 PROPANE	18	20	20	21	23	23	25	25		
	JS-0718-DM	JS-0720-DM	JS-0720-DM	JS-0721-DM	JS-0723-DM	JS-0723-DM	JS-0725-DM	JS-0725-DM		
225 NG	P	N	N	N	M	M	L	L		
	JS-070P-NS	JS-070N-NS	JS-070N-NS	JS-070N-NS	JS-070M-NS	JS-070M-NS	JS-070L-NS	JS-070L-NS		
225 PROPANE	#16	18	18	18	19	19	20	20		
	JS-0716-NS	JS-0718-NS	JS-0718-NS	JS-0718-NS	JS-0719-NS	JS-0719-NS	JS-0720NS-	JS-0720-NS		
250 NG	R	P	P	P	O	O	N	N		
	JS-070R-NS	JS-070P-NS	JS-070P-NS	JS-070P-NS	JS-0700-NS	JS-0700-NS	JS-070N-NS	JS-070N-NS		
250 PROPANE	#14	16	17	17	18	19	19	19		
	JS-0714-DM	JS-0716-DM	JS-0717-DM	JS-0717-DM	JS-0718-DM	JS-0719-DM	JS-0719-DM	JS-0719-DM		

15. REPLACEMENT PARTS: BURNER (Single-Stage and Two-Stage)



#	PART DESCRIPTION	MODEL	GAS TYPE	PART #	PART DESCRIPTION PRIMARY
1	BURNER CHAMBER	ALL	NG; Propane	JS-0504-SS-TM	SSTM Burner Chamber
2	BURNER CUP	ALL	NG; Propane	JS-0512-SS-TM	SSTM Burner Cup - Steel
3	MAIN BURNER ORIFICE	50	NG	JS-0729-DM	Gas orifice low intensity heater: 29 Number Size
		50	Propane	JS-0746-DM	Gas orifice low intensity heater: 46 Number Size
		GE	NG	JS-0723-DM	Gas orifice low intensity heater: 23 Number Size
		00	Propane	JS-0741-DM	Gas orifice low intensity heater: 41 Number Size
		00	NG	JS-0717-DM	Gas orifice low intensity heater: 17 Number Size
		00	Propane	JS-0737-DM	Gas orifice low intensity heater: 37 Number Size
		445	NG	JS-0702-DM	Gas orifice low intensity heater: 2 Number Size
		115	Propane	JS-0731-DM	Gas orifice low intensity heater: 31 Number Size
		120	NG	JS-0701-DM	Gas orifice low intensity heater: 1 Number Size
		130	Propane	JS-0730-DM	Gas orifice low intensity heater: 30 Number Size
		166	NG	JS-070G-NS	Gas orifice low intensity heater: G Letter Size
		155	Propane	JS-0726-DM	Gas orifice low intensity heater: 26 Number Size
		190	NG	JS-070M-NS	Gas orifice low intensity heater: \mathbf{M} Letter Size
		100	Propane	JS-0721-DM	Gas orifice low intensity heater: 21 Number Size
		205	NG	JS-070R-NS	Gas orifice low intensity heater: R Letter Size
		205	Propane	JS-0718-DM	Gas orifice low intensity heater: 18 Number Size
		225	NG	JS-070P-NS	Gas orifice low intensity heater: P Letter Size
		225	Propane	JS-0716-DM	Gas orifice low intensity heater: 16 Number Size
		250	NG	JS-070R-NS	Gas orifice low intensity heater: R Letter Size
		250	Propane	JS-0714-DM	Gas orifice low intensity heater: 14 Number Size
4	BURNER CUP ACCESS CAP	ALL		JS-0504-SS-TAD	Removable cap to access burner cup and orifice
5	SIGHT GLASS ASSEMBLY	ALL		JS-0536-XX	Sight glass assembly - tube heater
6	IGNITER KIT	ALL		JA-0571-KT	Igniter & gasket kit / DSI tube heater
7	IGNITION CABLE	ALL		JS-0518-SA	Hi voltage wire (24") - 2 x 1/4" Spades
9	BLOWER GASKET	ALL	Each	JS-0591-ST	SST Blower Gasket

#	PART DESCRIPTION	MODEL	MOD G	EL DASH #/ AS TYPE	PART#	PART DESCRIPTION PRIMARY
10	EQUALIZER PLATE	50	NG;	Propane	JS-0593-SK	SST Outlet equalizer plate 50
		65 & 80	NG;	Propane	JS-0593-SM	SST Outlet equalizer plate 65 & 80
		115 to 155	NG;	Propane	JS-0593-SV	SST Outlet equalizer plate 115, 130 & 155
		180	NG;	Propane	JS-0593-SW	SST Outlet equalizer plate 180
		205	NG;	Propane	JS-0593-SH	SST Outlet equalizer plate 205
		225 & 250	NG;	Propane	JS-0593-SV	SST Outlet equalizer plate 225 & 250
11	24 VDC BLOWER ASSEMBLIES	50 to 205	NG;	Propane	JS-0579-43	24 VDC, 43W Blower Assembly - 50 to 205
		225 & 250	NG;	Propane	JS-0579-63	24 VDC, 63W Blower Assembly - 225 & 250
12	BLOWER INTAKE RESTRICTOR	50 & 65	NG;	Propane	JS-0595-SC- M	Blower Air Intake Restrictor: 1.25 inch Hole
		130	NG;	Propane	JS-0595-SE	Blower Air Intake Restrictor: 1.5 inch Hole
		80 & 115	NG;	Propane	JS-0595-SF	Blower Air Intake Restrictor: 1.75 inch Hole
		155	NG;	Propane	JS-0595-SG- M	Blower Air Intake Restrictor: 2.75 inch Hole
		180 & 205	NG;	Propane	JS-0595-SH	Blower Air Intake Restrictor: 3.625 inch Hole
		225 & 250	NG;	Propane	JS-0595-SG- M	Blower Air Intake Restrictor: 2.75 inch Hole
13	AIR PRESSURE SWITCH	50	NG;	Propane	JS-0595-YZ	Air proving Switch 1.30" WC
		65	NG;	Propane	JS-0576-XY	Air proving Switch 1.15" WC
		80	NG;	Propane	JS-0575-ZA	Air proving Switch 1.40" WC
		115 to 205	NG;	Propane	JS-0575-UL	Air proving Switch 0.70" WC
-		225 & 250	NG;	Propane	JS-0576-XY	Air proving Switch 1.15" WC
17		ALL				1/2" x Pipe Nipples, Union and Elbow
18	GAS VALVE - SINGLE STAGE	50 to 155	NG		JL-0701-AA	Valve gas comb 3.5" WC 24VAC VR8 NG
		50 to 155	Pro	pane	JL-0703-AA	Valve gas comb 10" WC 24VAC VR8 LP
		180 to 250	NG		JA-0506-XX	Gas Valve - Slow Open 3.5" WC NG
		180 to 250	Pro	pane	JA-0507-XX	Gas Valve - Slow Open 10" WC LP
	GAS VALVE - TWO-STAGE	ALL	NG	Only	JA-0506-11	Gas Valve Two-stage- Slow Open -3.5"/2.2" (VR8205)
20	120VAC to 24VDC POWER SUPPLY	50 to 205	NG;	Propane	JA-0775-SB	120VAC to 24VDC Power Supply, 50 to 205
		225 & 250	NG;	Propane	JA-0775-SC	120VAC to 24VDC Power Supply, 225 & 250
21	INPUT	ALL			JS-0568-CC	Thermostat Relay- 24V
22		ALL			JA-U//5-XX	I ransformer 120/24V, 20VA A I 120B1028
23		ALL			JA-0567-XX	3- I rial 24 Vac with blower relay
24		ALL	Еас	n	JM-0455-DD	Terminal block (2)
25		ALL			JB-0567-XX	Cord - electrical 6
20		ALL			JS-0581-51-F	Component mounting plate SSI – Flat
21			Fer	h	10-0002-01	Dumer nousing coated black
30		ALL	⊏ac		JA-UDID-SS	
31	COUPLER	ALL			JA-0516-SW	4 swaged tube coupler torctite

16. <u>REPLACEMENT PARTS:</u> TUBE SYSTEM SST- / IST- SERIES



#	PART DESCRIPTION	MODEL	NOTE	PART #	PART DESCRIPTION PRIMARY
40	SYSTEM TUBES:				
	PRIMARY COMBUSTION TUBE	50 to 205		JS-0501-SK	Aluminized Steel Tube with Holes + Rivet + Cou- pler
		225 to 250		JS-0500-SK	Stainless Steel Tube with Holes + Rivet + Coupler
	HEAT EXCHANGER TUBES	ALL		JS-0515-SW-P	Coated Steel Tube; 10 ft with swage
		50 to 205	Second Tube	JS-0515-SW-P	Coated Steel Tube; 10 ft with swage
		225 to 250	Second Tube	JS-0500-SK	Stainless Steel Tube with Holes + Rivet + Coupler
41	STAINLESS STEEL COUPLER + STAINLESS STEEL RIVET	225 to 250	1st to 2nd & 2nd to 3rd tube connections	JA-0516-RK	Tube Connection Kit: Coupler + Rivet (225 to 250: 1st to 2nd & 2nd to 3rd tube)
42	COUPLER - Aluminized Steel	ALL		JA-0516-SW	4" swaged tube coupler torctite
43	REFLECTOR	STRAIGHT		JS-0502-ST	SST Single Tube Reflector x 120"
		U-TUBE		JS-0502-STU	U-Tube Double-Wide Reflector x 120" Length
		U-TUBE		JS-0502-STU-5	U-Tube Double-Wide Reflector x 60" Length
44	PLATE HANGER - BURNER END ONLY	ALL	Burner End ONLY	JS-0505-PH	SST Single Tube Plate Hanger (Burner End)
45	WIRE HANGER: TUBE / REFLECTOR	STRAIGHT		JS-0505-ST	SST Wire Hanger
		U-TUBE		JS-0505-SST-U	SST-U Wire Hanger
46	REFLECTOR END CAP:SINGLE TUBE	STRAIGHT	Vent End ONLY	JS-0502-EC	SST Series Reflector end cap: Single tube
	REFLECTOR END CAP: DOUBLE U-	U-TUBE		JS-0502-UT-R	SST-U Series Reflector end cap: Double U-tube
47	TURBULATOR	ALL	Refer to Table in Manual	JS-0533-TA	Turbulator 2.25" x 36"
48	90° ELBOW KIT	ALL	OPTIONAL	JS-0508-SST	90° elbow + Coupler + Reflector Cover
49	U-TUBE SECTION	U-TUBE		JS-0501-USST	ALUMINIZED "SSTU" TUBE SWAGED 60"
50	U-TUBE HANGER: TUBE / REFLEC- TOR	U-TUBE		JS-0505-SST-U	SST-U Tube Hanger, U-tube Models
51	HORIZONTAL VENT TERMINATION	ALL	OPTIONAL	JA-0528-XX	4" horizontal wall vent terminal